

Broil King®

















Broil King
ROYAL S340
9962-62
9962-63






Broil King
ROYAL S390
9962-82
9962-83

IM LIEFERUMFANG ENTHALTEN / MATERIAL INCLUS / CONTIENE FERRAMENTA


S21420		X2	S21124		X2
Y-12222		X1	Y-12223		X1
Y-11560		X4	Y-11793		X4
Y-29304		X2	Y-12865		X10
Y-12857		X2	Y-12124		X1
Y-11551		X1	Y-12673		X2
S35094		X2	S21061		X2

ERFORDERLICHE WERKZEUGE / OUTILS NECESSAIRES / UTENSILI NECESSARI




1








(2)




(2)








(1)




2




3



- (1)  AAA  (1)  (2)  (2) 




4





5

(4)  (2) 





6



(2) 





7



8





9





10


(1)



11






(1)









13

(1)









14

(1)




15

(1)














16


(2)



(2)









19

9962-82
9962-83



20


9962-82
9962-83



21

9962-82

9962-83



PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	9962-62	9962-63	9962-82	9962-83
1	10909-E401	CASTING BOTTOM	1	1	1	1
2	10473-E394	CASTING TOP	1	1	1	1
3	10081-BK630	NAMEPLATE	1	1	1	1
4	10958-E395A	TOP CASTING INSERT	1	1	1	1
5	10571-6	HEAT INDICATOR	1	1	1	1
6	10240-15	HINGE PIN	2	2	2	2
6A	S21237	HINGE SPACER	2	2	2	2
7	S21233	HITCH PIN CLIP	2	2	2	2
9	38170121	GRID - PORCELAIN	2	2	2	2
10	10222-E400	FLAV-R-WAVE	3	3	3	3
11	10225-E390	GRID - WARMING RACK	1	1	1	1
13	10184-R83	BOSS EXTENSION	1	1	1	1
15	52904-E400D	BURNER	3	•	3	•
	52904-E400E	BURNER	•	3	•	3
17	10342-246	ELECTRONIC IGNITOR	1	1	•	•
	10342-247	ELECTRONIC IGNITOR	•	•	1	1
18	10342-E12	ELECTRODE	2	2	2	2
19	10366-664A	COLLECTOR BOX	1	1	1	1
20	10111-16A	PIGTAIL HOSE ASSEMBLY	1	1	1	1
21	10444-E32D	CONTROL ASSEMBLY	1	•	•	•
	10444-E32E	CONTROL ASSEMBLY	•	1	•	•
	10444-E36D	CONTROL ASSEMBLY	•	•	1	•
	10444-E36E	CONTROL ASSEMBLY	•	•	•	1
21A	S13470-073	HOSE-SIDE BURNER	1	•	1	•
	S13470-079	HOSE-SIDE BURNER	•	1	•	1
21B	Y-11230	COTTER PIN	1	1	1	1
21C	10110-40	TUBE-REAR BURNER ASSY	•	•	1	1
23	10472-K431	CONTROL KNOB	4	4	5	5
30	10194-E755	CONTROL COVER	1	1	•	•
	10194-E795	CONTROL COVER	•	•	1	1
31	10711-E34	EDGE CAP - CONTROL COVER	1	1	1	1
32	10711-E33	EDGE CAP - CONTROL COVER	1	1	1	1
33	10184-F96	RADIATION SHIELD	1	1	1	1
34	10184-F97	GREASE RAIL	1	1	1	1
35	10184-E501	SUPPORT-CASTING-LEFT	1	1	1	1
36	10184-E511	SUPPORT-CASTING-RIGHT	1	1	1	1
37	10184-E651	SUPPORT-SIDE SHELF-LEFT	2	2	2	2
37A	10184-E63	SUPPORT-SIDE SHELF-LEFT	2	2	2	2
38	10184-E641	SUPPORT-SIDE SHELF-RIGHT	2	2	2	2
38A	10184-E62	SUPPORT-SIDE SHELF-RIGHT	2	2	2	2
39	10956-E881	BRACE-REAR	1	1	1	1
40	10958-E73	BASE	1	1	1	1
41	10956-E591	BRACE-FRONT	1	1	1	1
43	10958-E761	SIDE PANEL	2	2	2	2
44	10958-E901	PANEL - REAR	1	1	1	1
45	10184-E981	BRACKET - DOOR CATCH	2	2	2	2
48	10184-E691	SHELF BRACKET	1	1	1	1
50	10711-E822	SHELF - SIDE - RIGHT	1	1	1	1
51	10711-E832	SHELF-SIDEBURNER	1	1	1	1
56	10892-7G	WHEEL	2	2	2	2
60	10711-E49	END CAP - SHELF	2	2	2	2
66	S13005AE	BURNER ROTISSERIE	•	•	1	1
67	S15508	ELECTRODE	•	•	1	1
68	S21362	SPRING	•	•	1	1
69	10958-E49A	DOOR	1	1	1	1

PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	9962-62	9962-63	9962-82	9962-83
70	21071-13	HANDLE	1	1	1	1
71	10696-095	REARBURNER-ORIFICE	•	•	1	•
	10696-102	REARBURNER-ORIFICE	•	•	•	1
72	S21420	PUSH NUT	2	2	2	2
73	Y-11990	HEX NUT	•	•	1	1
74	S21084	SCREW - #14 x 3/4	3	3	3	3
75	24005-12AB	HANDLE	1	1	1	1
75A	10184-E12	RADIATION SHIELD	1	1	1	1
76	21070-13	HANDLE BEZEL	2	2	2	2
78	10892-15	CASTOR	2	2	2	2
79	Y-11561	BOLT – 1/4:20 x 1 3/4	12	12	12	12
80	Y-11546	SCREW- 1/4-20 X 5/8	8	8	8	8
81	Y-12860	SCREW – 1/4-20 X 1 3/8	4	4	4	4
82	Y-12673	SHELF - LOCK PIN	2	2	2	2
83	Y-12865	BOLT- 1/4-20 X 1/2	10	10	10	10
84	S15170	AXLE	1	1	1	1
85	Y-12855	SCREW- 1/4-20 X 3/8	8	8	8	8
86	Y-12310	SCREW - 1/4-20 X 3/4	2	2	2	2
87	Y-11793	NUT- 1/4-20	16	16	16	16
96	S21125	SCREW – 8 X 1/2	4	4	4	4
98	S21124	SCREW – 8 X 1/2	37	37	37	37
99	Y-12646	SCREW – SHOULDER 8 X 1/2	2	2	2	2
104	Y-12835	SCREW – 6-32 X 1/4	2	2	2	2
105	Y-12953	WASHER	2	2	2	2
106	Y-12861	SCREW – 1/4-20 X 3/8	2	2	2	2
107	Y-12863	WASHER	4	4	4	4
110	53140-981	GRID	1	1	1	1
111	10390-E10D	SIDE BURNER	1	•	1	•
	10390-E10E	SIDE BURNER	•	1	•	1
113	10342-T16	ELECTRODE – SIDE BURNER	1	1	1	1
114	23000-255	COVER-SIDE BURNER	1	1	1	1
115	Y-29304	SCREW 10-24 X 3/8	2	2	2	2
117	23000-271	SHELF-SIDE BURNER	1	1	1	1
122	57054-901	GREASE TRAY	1	1	1	1
123	52009-901	GREASE PAN	1	1	1	1
124	52049-91	SHIELD - GREASE TRAY	1	1	1	1
135	Y-12119	BUSHING	3	3	3	3
137	10184-E421	ROTISSERIE BRACKET	•	•	1	1
139	S21061	WING NUT	•	•	2	2
140	Y-29306	BOLT - 10-24 x 5/8	•	•	2	2
141	S15271	HANDLE	•	•	1	1
142	S15270	BALANCER	•	•	1	1
143	S15263	BUSHING	•	•	1	1
144	Y-12220	BUSHING	1	1	1	1
145	S15257	SPIT ROD	•	•	1	1
146	S15245	MOTOR	•	•	1	1
147	S15299	WASHER	•	•	1	1
148	S15287	4 PRONG FORKS	•	•	1	1
149	10240-20	DOOR PIN	1	1	1	1
151	Y-12857	WASHER	2	2	2	2
152	Y-12222	MAGNET	1	1	1	1
153	Y-12223	SNAP IN MAGNET	1	1	1	1
164	Y-12124	DOOR PIN CAP	1	1	1	1
165	Y-11551	SCREW - 1/4-20 x 1	1	1	1	1
166	Y-12117	BUSHING	2	2	2	2

