

The screw "H" are in part "I" and should be tightened from time to time.

